

SaferTouch™ Antimicrobial Touchscreens

Wet Application Instructions

1. Equipment Required:

SaferTouch antimicrobial film • Squeegee (or credit card) • Lint-free towel • 70% Isopropyl Alcohol in spray bottle

2. Surface Preparation:

All surfaces should be considered dirty and must be cleaned prior to the application of the film according to the recommended procedures from the manufacturer for those specific surfaces.

Plastics & Glass: Saturate a clean cloth with a 2 to 1 mixture of water and isopropyl alcohol and wipe surface with a dry lint free cloth. Use a window scraper to remove any build up on glass and perform an additional wipe down with a clean cloth with a 2 to 1 mixture of water and isopropyl alcohol

Application Temperature: Air and application surface must be above 32 degrees Fahrenheit for secure bond to form. A heat gun or hair dryer may help raise the temperature to meet this requirement.

3. Application Instructions:

The film is protected with a release liner which must be removed for application. Protect the front and back of the film during the installation procedure. Don't let it touch anything except the screen's surface.

After thoroughly cleaning the surface, wet it thoroughly with the alcohol solution and begin the installation.

As you pull the liner off of the film, begin to spray the film with solution, completely wetting it. Continue pulling on the release sheet while spraying the solution.

Discard the release liner safely. With the film surface completely exposed, spray one final time with solution to ensure that the film is wet.

Hold the film at the uppermost corners, being careful not to allow the film to touch the surface until pressure is applied. Place the film on the screen with the back side against the surface. The application solution acts as a lubricant making the screen and film surfaces slippery. You can now slide the film into the final position.

Beginning at the center of the screen, squeegee to the edge of the film. Then going back to the center, squeegee to the other edge of the film. Then squeegee the screen in straight, smooth strokes working from center out to the edges of the film until all excess solution has been removed from under the film. Ensure the film is lying flat. It is important to remove as much water and solution from under the film, so use firm even strokes. Allow to dry before use.

